



9. Mounting Parts For Air Controls And Lubricator



9. Mounting Parts For Air Controls And Lubricator



No.	Description	Modified		Ref. Part No.	QTY
1	Mounting Plate			5112084200	1
2	Air Control Bucket (See Page No. 21-22)			5032015586	1
3	Oil Lubricator (See Page No. 23-24)			5042016583	1
4	Air Control Traction Right (See Page No. 25)			5032015585	1
5	Air Control Traction Left (See Page No. 19-20)			5032015584	1
6	Silencer Element (Optional)		*	M10301	5
7	Cushion Plate Small			5104027700	1
8	Stud (Hex Bolt)			5104030500	6
9	Spacer			5104036000	8
10	Stud (Hex Bolt)			5104036100	3
11	Spring washer			0333213600	12
12	Nut			0266111200	12
13	Pin			0106228100	18
14	Hose Clam			0347450600	2
15	T - Pipe	5104028400	*	M10310	2
16	Stud (Hex Bolt)			5096993200	3
17	Cushion Plate big			5112055300	1
18	Link			5032027500	1
19	Connector tube			5032027600	1
20	Guard	5112114100	*	M10315	1
22	Screw			0147147700	2
23	Nut	0291111400	*	M10318	2
24	Gasket			0657586400	1
25	Plug			5032016400	1
26	O Ring			0663213600	1
27	Adapter			5032016500	1
	Hose Pipe Guard		*	M10323	1
	3 way valve for Dumping (See at Page No. 30)		*	M10658	1

Note : ① Reference Part Number Starting With 'M' - Is Modified